



Reliable Connections™

Drilling & Tapping
Machines

Operations Notice


This tool may be used with the “B-100/B-101”, “A-2” or “A-3” Tapping Machines.

To use with “B-100/B-101” Machine

This tool, with Retaining Pin in place, is ready to use with the tapping machine. Attach to machine Boring Bar in normal manner.

To use with “B”, “A-2” or “A-3” Machine

To use this tool with the machines simply remove the Retaining Pin from the Shank and insert into Machine Boring Bar in normal manner.



Phone: (800) 423-1323

By deviating from the above listed instructions, you will void any product warranty and release Mueller Co. and its affiliated entities from any and all liability associated with the installation or use of this product. For details on the product's warranty, terms, and conditions, please visit www.muellercompany.com.

© 2016 Mueller Co., LLC. All rights reserved.

Form 10708 04/16