



**Corporation  
Valves**

**Reliable Connections™**

## **Installation Instructions**

- Protect all threads from dirt or debris.
- Protect valve from impact – do not drop or throw.
- Never use a pipe wrench – use only a smooth-jawed wrench fully engaged on wrench flats provided on valve body.
- Use suitable sealant or joint-sealing tape on inlet threads.
- Use smooth-jawed wrench for final tightening of valve into main – never use tapping machine for this purpose.
- Read and understand any specific instructions applying to valve outlet connection and/or service line pipe/tubing – especially important when using plastic pipe/tubing.
- Use two smooth-jawed wrenches to connect service line – one on valve wrench flats to prevent it from turning in main, the other to tighten service line connection.
- Always pressure test for leakage before placing backfill.
- Do not allow pressurized valve to freeze.
- Do not use valve for throttling – valve must be fully open when service line is pressurized.

## **Phone: (800) 423-1323**

By deviating from the above listed instructions, you will void any product warranty and release Mueller Co. and its affiliated entities from any and all liability associated with the installation or use of this product. For details on the product's warranty, terms, and conditions, please visit [www.muellercompany.com](http://www.muellercompany.com).

© 2016 Mueller Co., LLC. All rights reserved.

Form 12609 04/16